

Advanced Optics (PHYS690)

HEEDEUK SHIN

POHANG UNIVERSITY OF SCIENCE AND TECHNOLOGY, KOREA



Laser

Light
Amplification by
Stimulated
Emission of
Radiation


- Laser history
- Gain media
- Light atom interaction
- Einstein coefficient
- Pumping




Laser

- Laser: a devices that produce intense beams of light.
- Monochromatic (pure color or wavelength)
- Coherent (fixed phase relationship)
- Highly collimated (low divergence)
- Small spot with a brightness which exceeds that of the sun.
- The first amplifier based on discrete energy levels (quantum amplifier) was the MASER (Microwave Amplification by Stimulated Emission of Radiation), which was invented by **Gordon, Townes** and **Zeiger** 1954.
- The basic operating principles of the laser were put forth by **Charles Townes** and **Arthur Schalow** from the Bell Telephone Laboratories in 1958, and the first actual laser, based on a pink ruby crystal, was demonstrated in 1960 by **Theodor Maiman** at Hughes Research Laboratories.

World's first working lasers



Ruby laser, 1960



GaAs semiconductor diode laser, 1962




HeNe laser, 1961
First gas & cw laser



Optical fiber laser, 1961

Laser

- Laser medium
- Pumping
- Resonator: laser oscillator or cavity





Laser Gain Media

Important characteristics of laser gain media

Solid, a gas or liquid

How population inversion can be achieved? (pumping schemes)

What the spectroscopic parameters are?


i.e. upperstate lifetime, T_1 , and linewidth $\Delta f_{\text{FWHM}} = \frac{2}{T_2}$

What is the **cross-section** for stimulated emission?



Light-matter interaction

- Consider an atom and consider two of its energy levels to be E_1 and E_2 (assume $E_1 < E_2$).




- Chose ν_0 such that


$$h\nu_0 = E_2 - E_1$$

the photon energy matches the energy-level difference.


- Three types of mechanism are possible:



– Spontaneous emission



– Absorption




– Stimulated emission

- Measure of the probability of absorption or emission of light by an atom
- The **Einstein A coefficient**: the rate of spontaneous emission of light
- The **Einstein B coefficients**: the absorption and stimulated emission of light

Einstein coefficients I

– Spontaneous emission

- Atom is initially in “excited” state E_2
- Atom decays spontaneously and add the energy $h\nu$ to the optical mode.
- The process is independent of the number of photon already in the optical mode, but dependent on the number of excited atoms.
- The number of atoms of the upper level: N_2
- The number of atoms of the lower level: N_1



The change dN_2 of the population N_2 within a time interval dt

$$dN_2 = -A_{21}N_2dt$$

A_{21} is the **Einstein coefficient of spontaneous emission**.

The population of the upper level decays exponentially

$$N_2(t) = N_2(0) e^{-A_{21}t} = N_2(0) e^{-t/\tau_{sp}}$$

τ_{sp} *spontaneous lifetime*

$$A_{21} = 1/\tau_{sp}$$


Einstein coefficients II

– Absorption

- Atom is initially in state E1.
- Process is induced by a photon: the photon is annihilated and the atom goes into excited state E2.
- The change dN_1 of the ground state within a time interval dt

$$dN_1 = -B_{12}\rho(\nu_0)N_1dt$$


where B_{12} is the *Einstein coefficient of absorption* and ρ is the spectral energy density of radiation at frequencies around ν_0 .



Einstein coefficients III

– Stimulated emission


- Atom is initially in “excited” state E₂.
- The optical mode contains a photon.
- Atom may be induced to emit another photon into the same mode.
- This is the inverse of the absorption process.
- The presence of a photon in the mode stimulates the emission of a “clone” photon.
- The change dN_2 of N_2 within a time interval dt



$$dN_2 = -B_{21}\rho(\nu_0)N_2dt$$

where B_{21} is the *Einstein coefficient of stimulated emission*.

The Einstein Relations



- The rate of change of the population N_1 due to absorption is given by

$$(dN_1/dt)_{\text{abs}} = -B_{12} \rho(\nu_0) N_1$$

- The rate of change of the population N_2 due to stimulated emission is given by

$$(dN_2/dt)_{\text{stim}} = -B_{21} \rho(\nu_0) N_2$$

- The rate of change of the population N_2 due to spontaneous emission is given by

$$(dN_2/dt)_{\text{sp}} = -A_{21} N_2$$

Einstein coefficients V

- In thermal equilibrium
- The ratio N_2/N_1 is a constant.
- The absorption rate has to be equal to the emission rate.

$$(dN_1/dt)_{\text{abs}} = (dN_2/dt)_{\text{sp}} + (dN_2/dt)_{\text{stim}}$$

$$B_{12}\rho(\nu_0)N_1 = A_{21}N_2 + B_{21}\rho(\nu_0)N_2$$

- From this equation, we can determine the spectral energy density

$$\rho(\nu_0) = \frac{A_{21}/B_{21}}{(B_{21}/B_{12})N_1/N_2 - 1}$$

- The ratio N_1/N_2 can be determined by the Boltzmann factor.

$$N_2/N_1 = e^{-h\nu_0/kT}$$

Planck's radiation law

$$\rho(\nu) = \frac{8\pi\nu^2}{c^3} \frac{h\nu}{e^{h\nu/kT} - 1}$$

$$B_{21} = B_{12},$$

$$A_{21} = \frac{8\pi\nu^2}{c^3} h\nu B_{21}$$

$$B_{21} = B_{12}$$

- The probability density of spontaneous emission of an atom is

$$P_{sp} = \frac{c}{V} \sigma(\nu)$$

- The process of absorption is governed by same law as in spontaneous emission with n photons in the optical mode.

$$P_{ab} = \frac{nc}{V} \sigma(\nu)$$

This is the probability of absorption of one photon from a mode with n photons.

- The probability density of stimulated emission is same law that governs spontaneous emission and absorption

$$P_{st} = \frac{nc}{V} \sigma(\nu)$$

$$P_{ab} = P_{st} \qquad B_{21} = B_{12}$$

Gain coefficient I

- Consider an atom located in an optical field of flux φ . The probability of stimulated emission is

$$W_i = \varphi \sigma(\nu)$$

- If N_1 and N_2 are respectively the number of atoms in the lower and upper energy level then
 - The average density of absorbed photons (number of photon per unit time per unit volume) is $N_1 W_i$
 - The average density of stimulated photons is $N_2 W_i$
- The net number of photon gained is


$$N = (N_2 - N_1) W_i$$

N is the population density difference.


- $N > 0$ **population inversion** (more atoms in excited states): medium can act as an amplifier.
- $N < 0$ medium act as an absorber.
- $N = 0$ medium is transparent.

Population inversion

- Under thermal equilibrium conditions, the lower energy levels are populated first, and are always more populated than the higher levels.
- If the laser really was a simple two level system, what could you deduce about the “colour” of the absorbed and the stimulated photons?




- Under thermal equilibrium conditions, the lower energy levels are populated first, and are always more populated than the higher levels.
- If the laser really was a simple two level system, what could you deduce about the “colour” of the absorbed and the stimulated photons?



Pumping

- To provide $N > 0$ (Population inversion), we need an external pump that excites the atom.
- External pumping is achieved via radiative or non radiative effects:
 - Optical pump,
 - Chemical reaction
 - Electrical process
- Pump should provide pumping to excite the needed state (directly or indirectly).



- Pumping dynamics is described by the **rate equations**: which provide the change of population densities N_1 and N_2 .



Pumping - rate equations


- When pumping is provided the rate of increase of population densities is

$$\frac{dN_2}{dt} = R_2 - \frac{N_2}{\tau_2}$$
$$\frac{dN_1}{dt} = -R_1 - \frac{N_1}{\tau_1} + \frac{N_2}{\tau_{21}}$$

R_1 : rate of pumping atoms out of state 1

R_2 : rate of pumping atoms into state 2

“rate” are per unit volume per second



- Steady-state condition is

$$N_0 = R_2 \tau_2 \left(1 - \frac{\tau_1}{\tau_{21}} \right) + R_1 \tau_1$$

Steady-state population difference

- To have a large gain

- Large R_1 and R_2

- Long τ_2


- Short τ_1 if $R_1 < \tau_2 / \tau_{21} R_2$

- Upper level should be pumped strongly and decay slowly.


- Lower state should be depumped strongly so it quickly disposes its population.

Pumping schemes

Four level pumping




Three level pumping





HW: Why cannot two-level system be used for a gain medium?

Stimulated Emission in a Mirrored Laser Cavity




Light Amplification by Stimulated Emission of Radiation


- Laser gain medium
- Pumping
- Resonator: laser oscillator or cavity



– Spontaneous emission



– Absorption



– Stimulated emission

$$B_{21} = B_{12},$$

$$A_{21} = \frac{8\pi\nu^2}{c^3} h\nu B_{21}$$

- The **Einstein A coefficient**: the rate of spontaneous emission of light
- The **Einstein B coefficients**: the absorption and stimulated emission of light

population inversion (more atoms in excited states): medium can act as an amplifier.

- Upper level should be pumped strongly and decay slowly.
- Lower state should be depumped strongly so it quickly disposes its population.

$$I = \frac{I_0}{|1 - h|^2} = \frac{I_0}{1 + |r|^2 - 2|r| \cos \phi}$$



$$I = \frac{I_{max}}{1 + (2\mathcal{F}/\pi)^2 \sin^2(\phi/2)}$$

$$\mathcal{F} \equiv \frac{\pi \sqrt{|r|}}{1 - |r|}$$

$$I_{max} \equiv \frac{I_0}{(1 - |r|)^2}$$

$$Q \stackrel{\text{def}}{=} \frac{f_r}{\Delta f} = \frac{\omega_r}{\Delta \omega},$$

$$\mathcal{F} \equiv \frac{\nu_{FSR}}{\Delta \nu} = \frac{\lambda_{FSR}}{\Delta \lambda}$$

$$Q = \nu_0 T_{rt} \frac{2\pi}{\eta}$$

POSTECH
Advanced Optics class